



## WXA Wireless - connected by AT&T

This Quick Setup guide is intended to get you up & running. For more details about the cameras features & functions please consult the full user manual.

The WXA is connected by and certified to run on the AT&T network. For convenience we have included an AT&T Sim card with the camera. If you are already an AT&T customer you may be able to add the camera to your existing plan. Contact AT&T for details. If you do not already have an AT&T account or wish to run your camera on a different plan you may go to their Buy A Session website for pay as you go options. Details below.

This Activation process is for an individual sim card, and individual camera. Once your plan is activated, you can manage your plan directly on the website link below.

Prior to starting the process please be sure to install batteries & SD card into your WXA Camera. You will also need to download the FREE Stealth Cam REMOTE app from either the Apple APP Store or Android Google Play and set up your Stealth Cam wireless account.

### Activation Steps

#### Step 1.

Use the link <https://buvasession.att.com> to start your activation process.

#### Step 2.

Create a new AT&T user name and password, or use your existing account info. We recommend using the same information to set up your user name and password for your Stealth Cam REMOTE APP and wireless camera. If using an existing account, click on "log in" and follow on to step 3. If you are a new AT&T customer, please click on "Get Your Pass" and proceed to step 4.

#### Step 3.

Existing customers click on "Add a Device"

#### Step 4.

Enter your IMEI number. Your IMEI number can be found by putting your wireless camera in the "Test" position and the number will appear at the bottom of your LED screen. This is a 15 digit number.



#### Step 5.

Enter your ICCID number found on the back of your included AT&T sim card holder. Please note, this number is not on the actual sim card itself; but rather, on the sim card holder (approximately the size of a credit card).

#### Step 6: Create a device nickname

Step 7a: If you are a new customer, you will have to enter all your set up information, determine a payment plan with applicable payment information, and review all account information for accuracy.



Step 7b: If you are an existing customer, once you've successfully entered all of your information you'll need to click on "Manage your Data" to select a data plan and proceed with payment.

Step 8: Once you have a data plan successfully purchased, insert your sim card into your wireless camera (with batteries and SD already inserted) Move the camera's power switch to the ON position. Press the MENU button, then the DOWN arrow to CELLULAR SETTINGS, press ENTER to bring you to the CELLULAR WIZARD. Press ENTER twice to begin the WIZARD. Follow the prompts to select your language & time zone. The camera will then say CONNECTING TO NETWORK.... Then NETWORK FOUND.

At this point you will need to enter the same USER NAME and PASSWORD you created when setting up your Stealth Cam REMOTE APP. Once entered you will see the message CONNECTING TO ACCOUNT..... then ACCOUNT FOUND! – SET UP COMPLETE.

Step 9: Log in to the Stealth Cam REMOTE APP, swipe down & your XVA should appear. The default upload frequency is set to Twice A Day. We recommend going into the CELLULAR SETTINGS menu on the camera and changing the upload frequency to INSTANT. This will allow you to get some test photos to ensure the system is transmitting properly. After which you can adjust the UPLOAD FREQUENCY setting to best suit your needs.

Step 10: Get your WXA out in field and enjoy the convenience of checking your camera from virtually anywhere on your mobile device.

**Need assistance? Questions? Contact our Customer Service Center at 877-269-8490**

**[www.stealthcam.com](http://www.stealthcam.com)**