



P.O. Box 535878
Grand Prairie, TX 75053-5878

Toll Free number : 877 269 8490

EASY TOUCH DIGITAL TIMER INSTRUCTIONS

PLEASE READ ALL INSTRUCTIONS BEFORE ATTEMPTING TO SET THE CLOCK

*SETTING THE CLOCK TIME AND/OR PROGRAM TIME: THE HOUR – MINUTE – DAY ADVANCES AUTOMATICALLY
IF NO BUTTONS ARE PRESSED AFTER 6 SECONDS*

SETTING TIME OF DAY

- 1) Remove protective cover if installed.
Turn power switch to on, located inside battery compartment.
- 2) Press and hold down the “+” or “-“ button for 3 seconds.
- 3) The “HOUR” indicator will begin to flash. Press “+” or “-“ to adjust the hour. Release the button when desired hour is reached.
- 4) 6 seconds later the “MINUTE” indicator will flash. Press “+” or “-“ to adjust the minute. Release the button when desired minute is reached.
- 5) 6 seconds later the “DAY” indicator will flash. Press “+” or “-“ to adjust the day. Release the button when desired day is reached. Wait 6 seconds. Time is set.

SETTING FEED TIME (1ST SETTING)

- 1) Remove protective cover if installed.
- 2) Press the “PROG” button. The first program indicator digit will begin to flash in the bottom left corner of the LCD display.
- 3) Press the “PROG” button again to navigate through the 1st program setting. The hour indicator will begin to flash. Press “+” or “-“ to adjust the hour.
- 4) Press “PROG” to set the hour and advance to the “MINUTE” indicator. Press “+” or “-“ to adjust the minute.
- 5) Press “PROG” to set the minute and advance to the “DAY” indicator. Press “+” or “-“ to advance through the day selections. Stop when you reach your desired combination. The timer will return to the current time and day display.

NOTE: If you want the unit to operate at the same time every day of the week it is only necessary to set 1 program cycle for that time of day. However, every day of the week must be shown at the top of the LCD display for that cycle.

SETTING FEED TIMES 2-16 (FOR MULTIPLE FEEDINGS)

- 6) Press the “PROG” button. The first program indicator digit will begin to flash in the bottom left corner of the LCD display.
- 7) Press “+” to navigate to the next program cycle or “-“ to navigate to the last program cycle.
- 8) Repeat steps 2 through 4 above to set programs 2 - 16. When all desired programs have been set just wait 6 seconds and timer will return to current time and day display.

CANCEL PROGRAM FEED TIME

- 1) Press “PROG” button. Press “+” or “-“ to navigate to desired program cycle you want to cancel.
- 2) Press and hold the “PROG” button until time display clears hour and minutes. (3 seconds.) Wait! The timer will return to current time and day display after approximately 20 seconds.

RATE OF FEED

- 1) Press “TEST” button, the feed rate duration indicator is displayed.
- 2) Press “+” or “-“ to adjust the duration time (1-30 seconds.) The timer will return to current time and day display after approximately 30 seconds.
- 3) Feed rate length is adjustable from 2 to 30 for each of the 16 separate settings.

TIMER RESET

Press yellow recessed “R” button. The current clock setting will reset to 12:00 A.M. Monday, and all program cycle settings will be reset as well.

TEST

- 1) Press “TEST” button, the feed rate duration indicator is displayed.
- 2) Press “TEST” button again to activate test. USE CAUTION! There is a 5 second delay. The timer will return to current time and day display after approximately 30 seconds.